

<b>5P-II FLAME POWDER GUN</b>			
<b>Pos.</b>	<b>FST p/n</b>	<b>Product Description</b>	<b>OEM / Remark</b>
	<b>331.000</b>	5P-II Flame powder spray gun complete	
	<b>331.000-01</b>	5P-II Flame powder spray gun	incl. vibrator and transformer
	<b>331.100</b>	Air jet	2PSA
1	<b>331.030</b>	Canister cover	5P 590
2	<b>331.031</b>	U-Cup	5P 91
3	<b>331.010-01</b>	Canister	5P 581
4	<b>331.032</b>	Canister clamp handle	5P 66
5	<b>331.033</b>	Connection block mounting screw	5P 199
6	<b>331.018</b>	Hose connection block	5P 197
7	<b>331.034</b>	Connection block O-Ring	5P 137
8	<b>331.035</b>	Plunger spring	5P 194
9	<b>331.036</b>	Plunger O-Ring	5P 80
10	<b>331.037</b>	Plunger	5P 192
11	<b>331.028</b>	Plunger seal O-Ring	5P 191, fuel gas and oxygen
12	<b>331.038</b>	Air hose connection	5P 98
13	<b>331.039</b>	Mounting screw, short	5P 102
14	<b>331.040</b>	Mounting screw, long	5P 103
15	<b>331.041</b>	Valve handle	5P 189
16	<b>331.042</b>	Valve handle screw	5P 68
17	<b>331.043</b>	Detent pin	5P 188
18	<b>331.044</b>	Detent pin spring	5P 196
19	<b>331.045</b>	Valve block	5P 186
20	<b>331.027</b>	Valve core O-Ring	5P 195
21	<b>331.046</b>	Gas connecting tube	5P 34
22	<b>331.047</b>	Valve core	5P 187
23	<b>331.048</b>	Knob set screw	5P 541
24	<b>331.049</b>	Retainer	5P 39
25	<b>331.050</b>	Dial plate	5P 38
26	<b>331.051</b>	Valve knob	5P 552
27	<b>331.052</b>	Knob stem O-Ring	5P 135
28	<b>331.053</b>	Flow control valve	5P 526
29	<b>331.054</b>	Detent pin	5P 36
30	<b>331.055</b>	Detent spring	5P 37
31	<b>331.056</b>	Bolt housing mounting screw, back	5P 49
32	<b>331.057</b>	Bolt housing mounting screw, front	5P 64
33	<b>331.006</b>	Metering Valve #11	5P-8-11
	<b>331.058</b>	Metering Valve #12	5P-8-12

<b>5P-II FLAME POWDER GUN</b>			
<b>Pos.</b>	<b>FST p/n</b>	<b>Product Description</b>	<b>OEM / Remark</b>
	331.059	Metering Valve #15	5P-8-15M
	331.012	Vibrator unit complete, incl. transformer	5P 803
34	331.004	Valve tube	5P 141
35	331.061	Plate mounting screw	5P 62
36	331.062	Bolt housing	5P 46
37	331.063	Valve bolt	5P 40
38	331.064	Gun body assembly	5P 625
39	331.065	Trigger	5P 30
40	331.066	Stud nut	5P 123
41	331.067	Tool post bracket	5P 121
42	331.068	Lockwasher	5P 124
43	331.069	Mounting stud	5P 122
44	331.070	Handle	5P 627
45	331.071	Handle assembly screw	5P 28
46	331.072	Handle mounting screw	5P 67
47	331.021	Gas tube O-Ring	5P 184
48	331.073	Aspirator jet screw	5P 1
49	331.007	Standard Spray Siphon plug	5P 585
50	331.015	Baffle	5P 266
51	331.016	Baffle retaining ring	5P 167
52	331.022	Siphon plug O-Ring	5P 516
53	331.074	Sleeve	5P 519
54	331.023	Aspirator O-Ring	5P 515
55	331.075	"B" nozzle	5P 7B-B
	331.029	"D" nozzle	5P 7B-D
	331.017	"F" Nozzle	5P 7B-F
	331.003	"G" Nozzle	5P 7B-G
	331.076	"N" Nozzle	5P 7B-N
	331.077	"K" Nozzle	5P 7B-K
	331.078	"M" nozzle	5P 7B-M
56	331.085	O-Ring	5P 108
57	331.086	Nozzle nut	5P 575
58	331.087	Air cap	5P 576
	331.088	Air bleeder cap	5P 577
59	331.081	Air cap body	5P 501
60	331.082	Ratchet	5P 53
61	331.083	Override spring	5P 51
62	331.084	Override bar	5P 50

<b>6P-II FLAME POWDER GUN</b>			
<b>Pos.</b>	<b>FST p/n</b>	<b>Product Description</b>	<b>OEM / Remark</b>
	<b>330.000</b>	6P-II Flame powder spray gun complete	
1	<b>330.041</b>	Screw, connection block mounting	6P 199
2	<b>330.040</b>	Hose connection block	6P 197
3	<b>330.030</b>	O-Ring, connection block	6P 137
4	<b>330.037</b>	Spring, plunger	6P 194
5	<b>330.019</b>	O-Ring, plunger	6P 80
6	<b>330.036</b>	Plunger	6P 192
7	<b>330.035</b>	O-Ring, plunger seal	6P 191
8	<b>330.025</b>	Air hose connection	6P 98
9	<b>330.026</b>	Powder feed tube	6P 101
10	<b>330.016</b>	Screw, mounting	6P 77
11	<b>330.017</b>	Lock washer	6P 78
12	<b>330.024</b>	Gas valve block	6P 92
13	<b>330.032</b>	Valve core assembly	6P 187
14	<b>330.038</b>	O-Ring, valve core	6P 195
15	<b>330.014</b>	Screw, valve handle mounting	6P 68
16	<b>330.034</b>	Valve handle assembly	6P 189
17	<b>330.033</b>	Detent pin	6P 188
18	<b>330.039</b>	Spring, detent pin	6P 196
19	<b>330.015</b>	Gas connection tube	6P 72
20	<b>330.013</b>	Screw, top plate mounting	6P 67
21	<b>330.031</b>	Top plate	6P 169
22	<b>330.011</b>	Screw, plate mounting	6P 29
23	<b>330.012</b>	Gun body assembly	6P 40
24	<b>330.001</b>	O-Ring, connection tube	6P 24
25	<b>330.049</b>	Screw, handle assembly mounting	6P 287
26	<b>330.047</b>	Handle mounting plate	6P 285
27	<b>330.023</b>	Screw, mounting plate	6P 88
28	<b>330.074</b>	Nut	6P 283
29	<b>330.045</b>	Tool post bracket	6P 281
30	<b>330.046</b>	Lock washer, mounting stud	6P 284
31	<b>330.073</b>	Mounting stud	6P 282
32	<b>331.070</b>	Handle	5P 627
33	<b>330.050</b>	Screw, handle assembly	6P 288
34	<b>330.018</b>	O-Ring, siphon plug, small	6P 79
35	<b>330.058</b>	Siphon plug, 2 jet	6P 600

<b>6P-II FLAME POWDER GUN</b>			
<b>Pos.</b>	<b>FST p/n</b>	<b>Product Description</b>	<b>OEM / Remark</b>
	<b>330.060</b>	Siphon plug, 4 jet	6P 605
36	<b>330.020</b>	O-Ring, siphon plug, large	6P 81
37	<b>330.055</b>	Baffle, brass	6P 518
38	<b>330.022</b>	Baffle retaining ring	6P 84
39	<b>330.021</b>	Sleeve	6P 82
40	<b>330.042</b>	O-Ring, nozzle, small	6P 217
41	<b>330.004</b>	"D" nozzle	6P 7C-D
	<b>330.005</b>	"F" nozzle	6P 7C-F
	<b>330.006</b>	"K" nozzle	6P 7C-K
	<b>330.007</b>	"M" nozzle	6P 7C-M
	<b>330.008</b>	"MH" nozzle	6P 7C-MH
42	<b>330.043</b>	O-Ring, nozzle, large	6P 218
43	<b>330.057</b>	Nozzle nut	6P 525
44	<b>330.002</b>	Air cap, gun cooling	6P 4
	<b>330.009</b>	Air cap, pinch-cool	6P 3
45	<b>330.028</b>	Air cap body	6P 117
<b>OTHERS</b>			
	<b>120.410</b>	Dual Gas flow tubes	
	<b>330.003</b>	Gas valve assembly	6P 5
	<b>330.044</b>	O-Ring package, gas valve	6P 280, incl. 330.019, 030, 035, 038
	<b>330.054</b>	Control handle assembly	6P 510
	<b>330.072</b>	Siphon plug spare parts	6P 855, incl. 330.018, 020, 022, 055
	<b>330.100</b>	Gas/Air panel complete	

*NOTE: in this Consumable Guide the most generally industrial used spare parts are listed. If products other than listed in this catalogue are required, please contact our customer support team.*